



HUNTER®
MARINE CORPORATION
AN EMPLOYEE OWNERSHIP COMPANY

March 6, 2006

Liberty Capacity Label Installation Instructions

Included items:

1. New capacity label as shown:
2. Directions



Installation procedure:

1. Locate old capacity plate inside transom on port side:



2. Peel off old label using your fingernail or some other tool to get under the edge of the label and pull it off slowly.



P.O. Box 1040 • US Hwy 441 • Alachua, FL 32615
www.huntermarine.com
386.462.3077 • FAX: 386.462.4077

3. Clean the area (if dirty) with alcohol or soap and water and be sure that the area is dry. Peel off the paper backing of the new label, keeping the adhesive clean, and place it in the same area inside the transom. Make sure that it is well-adhered by rubbing it hard with your hand or a clean dry cloth.



Note: If the old label won't come off you may place the new one directly over the old one. Be sure that the area is clean and dry first.